

# Remote Control User Guide

## Big Button - GVTV

### TV, Set-Top-Box

Use one remote to control multiple devices.

### Menu

Displays the menu.

### Arrow Keys and OK/Sel

Navigate and select onscreen choices.

### Guide

Opens the Interactive Program Guide.

### Red, Green, Yellow, Blue

Access additional features on your set-top box.

### Vol +/-

Raise or lower the volume.

### Mute

Turn the sound off or on.

### On Demand

Access video on demand services.

### Aspect Ratio \*

Temporarily change the conversion mode from Original Size or Fit to Screen.

\*If Available



### Off

Turn on/off a selected device.

### Info

Display the current channel and program information. Press again for more detail.

### Exit

Exit the current screen.

### Page +/-

Page up or down in lists and Interactive Program Guide.

### Channel +/-

Changes to the next higher or lower channel.

### Last

Recall the last channel you were watching.

### FAV

View your favorite channels.

### Number Keys (0-9)

Directly select a channel or enter options.

### Input

In TV control mode, will change the input of the device you are controlling.

## WHAT'S ON TV?

There's more than one way to see what's showing on TV.

**Info Button:** Press Info and you will see the name and description of the current program at the top of the screen.

**OK Button:** Press OK to show the 'Now Playing' bar and you will see what program is currently playing.

**Guide Button:** This is the most comprehensive view of what's on. Go ahead and page through, you're bound to find something to watch.

**Browse Button:** Press Browse (right arrow) to show the channel you are currently tuned to at the top of the screen. At the bottom of the screen, the 'Info Bar' shows you the channel number, channel name, current date and time, program name, date and time the program airs, a progress bar, and the program that airs next.

2.12.18